

**TV**  
Controls TV functions

**Power**  
Turns components On/Off

**STB**  
Used for Set Top Box functions

**Channel +/-**  
Changes channels on the STB

**Guide**  
Displays programming guide

**Exit**  
Exits any menu or guide

**Arrows**  
Allows you to scroll through the Guide

**OK**  
Press when you want to select a program or highlighted object

**Currently Not Used**

**Delete**  
Deletes single character in text entry boxes

**Turning ON and OFF Television**

To turn on TV press TV then **POWER**  
Press STB to control our set top box  
To turn off TV press TV then **POWER**

**AV**  
Switches between audio video inputs on your TV

**Volume +/-**  
Increases/Decreases volume

**Menu**  
Displays main menu

**Tools**  
Currently not used

**Info**  
Displays information about current program  
\*When pressed twice, shows additional information

**Page Up/Down**  
Scrolls Up and Down from the current page in the guide

**Page Back/Forward**  
Scrolls Side to Side from the current page in the guide

**Number Keys**  
Used for typing in channels numbers and alphabet letters

**Last Channel**  
Returns your programming back to the previous channel

**PVR/VOD Keys**  
For use with PVR/VOD Functions

